

# INSTRUCTIONS

**MODEL:** HONDA TRANSALP 700

**PRODUCT:** SOFT BAGS SUPPORT



## CONTENTS

2 pc. Black metal holders for bag support  
2 pc Screw allen M8 x 125 x 7  
2 Screw M8 x 125 x 3  
4 pc Lock nut 8 x 125  
4 pc Grommet Ø 8  
2 bar



## Placement

1. Take off the saddle
2. Take off the screw (photo 1).
3. Make in the same position of the screw holes with a drill (Ø 8). Put the allen screw.
4. Put on the base of the bag, on the base of the fellow passenger's (photo 2) with the defector.
5. Tighten the screws until they are pressed well enough.

## MATERIAL SPECIFICATIONS

The product's material, made of steel, is already powder painted black and is ready to be placed on your bike.