




SPIRIT HD

POCKET GUIDE

EN





Media

Volume Down

Mobile / Intercom

Volume Up

LED Indicator




Number of Taps




Press & Hold


Getting Started




On / Off



Phone Pairing







Download




Register




Choose Language





Software Update





General





Volume Up



Volume Down



Mute




Voice Assistant



Siri




Google Assistant




Phone Call




Answer



Ignore



End Call





Phone Call




Speed Dial

Set Number



Call Speed Dial




Radio





Set Presets

1





2




Start Scan

x3
Tap



Stop Scan


x1
Tap




Radio





On




Off



Next




Previous




Music


 Play




 Pause



 Next



 Previous




Bluetooth Intercom



Pairing



Pair to Rider A




LED Red 





Call / End Intercom

Rider A




Bluetooth Intercom



GPS Pairing


1 Step 1



LED Red & Blue




2 Step 2




LED Red & Green



3 Step 3





Cardosystems.com

Cardosystems.com/update

Cardosystems.com/support

